



# Lone Hanger

## Instructions

1. Pre-cut the siding.
2. Pre-drill the holes with countersink bit. Use screws to avoid damaging the siding – this also allows for ease of removal if needed.
3. Measure the starter row off the ground at desired location using preferred method (i.e., a chalk line, string line, pencil, laser, etc.)
4. Screw the first board in place and ensure it is level from corner to corner; this will be your anchor. Don't over drill your anchor screw.
5. Attach Lone Hanger to starter row to begin hanging your second row of siding. (Lone Hangers will support a twelve (12) foot piece of siding without having to hold it in place.)
6. Set the second row of siding and fill in pre-drilled holes with screws.
7. Remove the screws holding the Lone Hangers and use the tab on the end of one Hanger to smooth over the holes left by the screws. These may be filled with a dab of latex caulk.
8. Repeat steps three (3) through seven (7) until the siding is complete.